Installation Steps



Tools for the installation: An allen wrench size 6mm and a jaw wrench SW22

For all pipes with diameters \emptyset 10 to 42mm, 3/8" to 2" Tube (external \emptyset), and $\frac{1}{4}$ " to 3" pipe (internal \emptyset).

serv-Clip 1

for mounting on pressurized pipes

serv-Clip 2

for mounting on non-pressurized pipes









place of installation screw down clamp bolts

vn te

place of installation plunge the needle









remove paint

plunge the needle

remove paint and clean pipe

remove stirrup and needle









clean pipe

ready to measure

clamp SC onto pipe

screw valve



clamp SC onto pipe



screw down clamp bolts



ready to measure

Version: 06-2019